

# series SDT-3PB ... DIGITAL TIMER

## INSTRUCTIONS

### HOW TO START and STOP:

1. Press the "ON/OFF" key to Start or Stop the timer. The display will show the current time count. The "-" sign on the left hand side of the display may be flashing when the timer is counting.

### TIMER PRESET:

2. The user may preset the timer only when it is not during the count-down process. Press the UP or DN key to preset the desired time period. **NOTE:** For as long as the supply power is present, the TIMER preset value is saved in a temporary memory and may be recalled later on by pressing a key on the keypad. After each new Power Up the Preset Time is automatically set to the maximum for the particular timer model.

**NOTE:** In models with the "Delay-Before-Start" option, the load is switched OFF during the delay count-down.

### AUTOMATIC STOP:

The controller stops automatically and resets the timer to "0" when a malfunction is detected or the preset time expires.

### IDLE OPERATION:

The display shows "OFF" to indicate that the controlled load is switched OFF.

**CAUTION:** All installation and adjustments of the controller options **MUST** be done **ONLY** when **ALL POWER** to the load and the controller is disconnected.

### TROUBLESHOOTING:

Optional sensor wiring and controls are continually checked for proper operation. If a malfunction is detected, the controller will automatically switch OFF the load and deactivate itself. At the same time display will show "Err".

The controller cannot be reactivated until all causes of the malfunction are fixed.

